




Pivot Set. UB 16 Spring Ext Duty w/ Socket tubes


Part Number: 103093

103093 Pivot Set, UB - 16 Spring Ext Duty




Bom ID	Part#	Description	qty
1	101188	Socket Tube (Drilled & Tapped - 160")	2
2	101007	Pivot. UB Assembled 16-Spr Ext Duty Pass w/o tube	1
3	101006	Pivot. UB Assembled 16-Spr Ext Duty Drivers w/o tube	1

101006 Pivot, UB Assembled 16-Spr Ext Duty Drivers w/o tube




Bom ID	Part#	Description	qty
1	101004	Pivot Pin. for 16-Spring Ext Duty Roller Bearing - Driver	1
1.1	47010	Bushing. Pivot 1 1/4 Machinery Bushing for Pivot Pin	1
1.2	47000	Snap Ring. 1 1/4" External for Pivot Pin	1
2	47800	Bearing. Carrier Underbody Flanged	2
3	47230	Spring. Spiral Torsion Spring 1 1/4"	16
4	18120	Bolt. 3/8" x 1-1/2" Thread Cutting Screw Hex Washer Hd	8
5	102349	Plate. Al Front for Ext Bolt Flange Mount UB Box	1
6	102581	Bracket. Ext Body with holes for 16 Spr UB Box	1
7	102259	Plate. Al Back for Ext Bolt Flange Mount UB Box	1

47800 Bearing, Carrier Underbody Flanged



Bom ID	Part#	Description	qty
1	18628	Nut. Nylock nut 3/8" Jamb Nut	2
2	18242	Bolt. 3/8"-16 x 1 1/8" Button Head	2

101007 Pivot, UB Assembly 16 Spr Ext Duty w/o tube Pass Side, Each



Bom ID	Part#	Description	qty
1	101005	Pivot Pin. for 16-Spring Ext Duty Roller Bearing - Pass	1
1.1	47010	Bushing. Pivot 1 1/4 Machinery Bushing for Pivot Pin	1
1.2	47000	Snap Ring. 1 1/4" External for Pivot Pin	1
2	47800	Bearing. Carrier Underbody Flanged	2
3	47230	Spring. Spiral Torsion Spring 1 1/4"	16
4	18120	Bolt. 3/8" x 1-1/2" Thread Cutting Screw Hex Washer Hd	8
5	102349	Plate. Al Front for Ext Bolt Flange Mount UB Box	1
6	102581	Bracket. Ext Body with holes for 16 Spr UB Box	1
7	102259	Plate. Al Back for Ext Bolt Flange Mount UB Box	1